


Telescopic Adjustable Banner Stand Assembly Instructions



	2 x A
	2 x B1
	2 x B2
	2 x C
	4 x D 2 x E
	1 x F



When assembling 10x8, 8x8 banner stand:

Align and tighten each part of B1 & B2 poles to the silver line indicated. If you extend the pole beyond the silver line, the stand will not be as stable or sturdy.





Along with the stand poles, the package contains a long piece of string and four velcro strips.



You are NOT required to use these additional pieces for assembly.

Should you find that your banner is not as taut on the stand as you would like, you can use the string to tie together the vertical pieces to minimize bowing and the velcro strips to adhere the sides of the banner to the banner stand.


The velcro strips are to be used on the four corners of the banner stand.

For 10ft x 8ft Banner Stands Only



If you purchased a 10ft x 8ft banner stand, you will receive an extra pole that supports the middle of the stand.

Place the “U” shaped end through the 2” cut of your pole pocket to attach to the top horizontal pole.



There is a 2”-3” slit on the backside of the pole pocket. Slide the “U” shaped end through this slit and adjust the height to eliminate sagging in the middle of the upper horizontal bar.